



REGULAR DISPLAY AND BUTTON OPERATION

E-01




HOW TO CHANGE THE DISPLAY MODE

E-02




HOW TO DISPLAY CALENDAR

E-03




HOW TO SET NORMAL TIME

E-04




HOW TO SET NORMAL TIME

E-05




HOW TO SET ALARM TIME

E-06




HOW TO SET ALARM TIME

E-07




How to set the alarm, ringing on the hour and key tone

E-08




How to set the alarm, ringing on the hour and key tone

E-09




HOW TO USE THE CHRONOGRAPH

E-10




HOW TO USE THE CHRONOGRAPH

E-11




HOW TO USE TIMER

E-12




HOW TO USE TIMER

E-13




HOW TO SET SECOND TIME ZONE

E-14



HOW TO USE EL LIGHT

E-15



NOTE:

- This watch features an electro-luminescent (EL) backlight, which tends to lose illuminating power after very long use.
- The illumination provided by backlight may hard to see under direct sunlight.

CARE OF YOUR WATCH

E-16

- This watch contains precise electronic components. Never attempt to open the case or remove the back cover.
- Do not operate buttons while underwater, or while swimming or diving.
- Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.
- Avoid severe impact: The watch is designed to withstand impact under normal use. Do not subject it to severe impacts or rough usage, and do not drop it onto hard surfaces.
- Avoid exposing the watch to temperature extremes.
- Clean the watch with a soft cloth and clean water only. Avoid using chemicals, especially soap.
- Keep your watch away from strong electric fields and static electricity.

FEATURES AND SPECIFICATIONS

E-17

- Standard display mode: Hour, Minutes, Seconds, Month, Day of the week.
- Function:
 - Month, Date AM/PM and Electro-Luminescent light.
 - Alarm function with buzzer signal output.
 - Chronograph function with lap operation.
 - Hourly chime.
 - 12/24 hour format switch option.
 - Timer.
 - Second time zone.
- Accuracy at normal temperature (25°C): ± 30 seconds a month.
- Normal operating temperature range: 10°C ~ 40°C.

GUARANTEE CERTIFICATE CERTIFICAT DE GARANTIE

MODEL: _____
 MODELE: _____

DATE OF PURCHASE: _____
 DATE D'ACHAT: _____

OFFICE DEALER STAMP:
 TAMPON DU DETAILLANT OFFICIEL: