


55.00mm

 **MAXUM**

3-HANDS INSTRUCTION MANUAL

DISPLAY



***Firstly, unscrew crown by turning colunterclockwise

SETTING THE TIME

1. Pull the crown out to the 1st position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position.

***Finally, screw crown clockwise until tightly locked

REMARKS:

* Crowns must always be screwed tightly while in use.

Don't use the watch if the screwed crown is not completely locked.

60.00mm