


# USER'S GUIDE

YP19781B(SECONDS CARTOON, MULTIFUNCTION SPORT WATCH)

- Synchronize Movement
- LED Backlight
- Stopwatch
- World Time
- Countdown Timer
- Low power indicator
- 5 Alarms
- 100 Years Calendar
- Chime
- 100M Water Resistant
- Battery CR2016

## BUTTONS

- Button operation are indicated using the letters shown in the illustration.



- A -- Reset
- B -- Mode
- C -- LED backlight / -
- D -- Start / Stop / +

## LOW POWER

- If the battery voltage level is insufficient, the icon will appear to remind to replace a new battery.




## ATTENTION

1. Never try to open the case or remove its back cover.
2. Do not operate buttons underwater.
3. Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
4. Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
5. Avoid exposing the watch to temperature extremes.
6. Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
7. Avoid to wear the watch in electromagnetic, static conditions.

## DISPLAY

- The screen shown in below:




## LED BACKLIGHT

- The backlight that uses an LED, cause the display to glow for easy reading in the dark.

### Use Backlight

- In the timekeeping mode, quick press "C" to illuminate the LED about 3 seconds.



## MODE SELECTION

- Press "B" to change mode to mode in the following sequence:  
Timekeeping Mode → Stopwatch Mode → Countdown Mode → Alarm Mode → World Time Mode.


### a TIMEKEEPING

- 12/24H Format;
- Hour, Minutes, Seconds, Day of week, Month, Date;
- 100 years Calendar (2000 ~ 2099).



### b STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00"00 ~ 99:59'59".



### c COUNTDOWN

- Countdown range: 99:59'59" ~ 0'00"00.



### d ALARM

- 5 Alarms;
- Hourly time signal;
- The alarm sounds at the preset time every day.



### e WORLD TIME


- The time for other time zone.



## a TIMEKEEPING

### Calendar

- In the timekeeping mode, press and hold "D" to display: Year, Month, Date.



### Time Setting

1. In the timekeeping mode, press and hold "A" until the city code will flash (flashing is indicated in the setting mode);



2. Press "C" or "D" to select the city code, press and hold to adjust at high speed;



3. Press "B" to select the Daylight Saving Time;



4. Press "C" or "D" to turn ON/OFF the Daylight Saving Time.




5. Repeat steps 3 and 4, the selection in the following sequence:

City code - Daylight Saving Time - Seconds - Hour - Minutes - 12/24H Format - Year - Month - Date - Date Format - Key Tone(ON/OFF);

6. Press "A" to exit the set state after setting (The day of week is automatically displayed in accordance with year, month and date setting).

- When the digital time and hands they are not the same, please conduct the hands calibration function.



## World Time Form

City code	City	GMT Differential	Other major cities in same time zone
WLG	Wellington	+12	Christchurch, Nauru Island, Nadi
NOU	Noumea	+11	Port Vila
SYD	Sydney	+10	Melbourne, Guam, Rabaul
ADL	Adelaide	+9.5	Darwin
TYO	Tokyo	+09	Seoul, Pyongyang
HKG	Hong Kong	+08	Singapore, Kuala Lumpur, Beijing, Taipei, Manila
BKK	Bangkok	+07	Jakarta, Phnom Penh, Hanoi, Vientiane
RGN	Yangon	+6.5	
DAC	Dhaka	+06	Colombo
DEL	Delhi	+5.5	Mumbai, Kolkata, Colombo
KHI	Karachi	+05	Male
KBL	Kabul	+4.5	
DXB	Dubai	+04	Abu Dhabi, Muscat
THR	Tehran	+3.5	Shiraz

City code	City	GMT Differential	Other major cities in same time zone
JED	Jeddah	+03	Kuwait, Aden, Addis Ababa, Nairobi, Moscow
CAI	Cairo	+02	Athens, Helsinki, Istanbul, Beirut, Damascus, Cape Town
JRS	Jerusalem	+02	
PAR	Paris	+01	Milan, Rome, Amsterdam, Madrid, Algiers
LON	London	+00	Dublin, Lisbon, Casablanca, Dakar, Abidjan
RIO	Rio de Janeiro	-03	Sao Paulo, Buenos Aires, Brasilia, Montevideo
CCS	Caracas	-04	La Paz, Santiago, Port Of Spain
NYC	New York	-05	Montreal, Detroit, Miami, Boston, Panama City,
CHI	Chicago	-06	Houston, Dallas/Fort Worth, New Orleans,
DEN	Denver	-07	El Paso, Edmonton
LAX	Los Angeles	-08	San Francisco, Las Vegas, Vancouver, Seattle
ANC	Anchorage	-09	Nome
HNL	Honolulu	-10	Papeete
PPG	Pago Pago	-11	Pago Pago

## b STOPWATCH

### A Lap Time


1. In the stopwatch mode, press "D" to start the stopwatch;



2. To stop the stopwatch by pressing "D" again;



3. Press "A" to reset the stopwatch.



### Split Time

1. In the stopwatch mode, press "D" to start the stopwatch;



2. Press "A" to display the split time, stopwatch timing continues internally;



3. Press "A" to clear the split time and to continue time measurement;



4. Repeat step 2 and 3, you can measure the multi split time;

5. Press "D" to stop the stopwatch.

## c COUNTDOWN

- When the countdown reaches zero, the alarm sounds for about 10 seconds and press any button to stop it.

### Countdown Timer Setting


1. In the countdown mode, press and hold "A" until the hour will flash (flashing is indicated in the setting mode);



2. Press "D" to increase the hour, press "C" to decrease the hour, press and hold to adjust at high speed;



3. Press "B" to select the next selection;



4. Press "D" to increase the number, press "C" to decrease the number, press and hold to adjust at high speed;



5. Repeat steps 3 and 4, the selection in the following sequence:  
Hour → Minutes → Seconds;


6. Press "A" to exit the set state after setting.

### Use Countdown Timer

1. Press "D" to start the countdown timer;



2. To pause the countdown by pressing "D" again.



3. Press "A" to reset the countdown.

## d ALARM

- The alarm sounds at the preset time each day for about 10 seconds, press any button to stop it.

### Alarm and Chime

- In the alarm mode, press "C" to select chime, Alarm1 ~ Alarm5.



- In the chime state, press "D" to on/off the chime.




- In the Alarm1 ~ Alarm5 state, press "D" to on/off the alarm.




### Alarm1 Setting

1. In the alarm state, press and hold "A" until the hour will flash (flashing is indicated in the setting mode);



2. Press "D" to increase the hour, press "C" to decrease the hour, press and hold to adjust at high speed;



3. Press "B" to select the minutes;




4. Press "D" to increase the minutes, Press "C" to decrease the minutes, press and hold to adjust at high speed;



5. Press "A" to exit the set state after setting.



- Setting and operation of the Alarm1 ~ Alarm5 are the same.



## e WORLD TIME

1. In the world time mode, press "D" to forward select the time zone, press "C" to backward select the time zone, press and hold to adjust at high speed;




2. In the world time mode, press and hold "A" to turn ON/OFF the Daylight Saving Time.



## HANDS CALIBRATION

- Please ensure the digital time and hands at same time before using this watch, when they are not the same, please conduct the hands calibration function.



- In the timekeeping mode, press and hold "A", "B", "D" until enter to hands calibration state.

- In the hands calibration state, user adjust the time in compliance with time of hands, the current time setting see timekeeping mode.

- In the LCD flashing state when user change a new battery for the watch, press "A" switch to timekeeping mode, at the same time please conduct the hands calibration function.